


Einstellen des Wochentags, der Uhrzeit und des Datums

für die Chronographen mit dem Uhrwerk ISA 9238-1970, ISA 8172-220



Einstellen des Wochentags

Krone auf Position 3 bringen und den Minutenzeiger vorwärts bewegen, bis der gewünschte Wochentag eingestellt ist, anschließend Krone wieder auf Position 1 drücken.

Einstellen der Uhrzeit



Krone auf Position 3 bringen und Uhrzeit einstellen, anschließend Krone wieder auf Position 1 drücken. (Beim Einstellen bitte den 24 Stunden Rhythmus beachten.)

Einstellen des Datums

(nicht von 21.00 Uhr bis 0.30 Uhr) Krone auf Position 2 bringen und Datum einstellen, anschließend Krone wieder auf Position 1 drücken.

Setting the time, date and weekday

for chronographs with ISA 9238-1970, ISA 8172-220 movement



Setting the weekday

Pull the crown out to position 3 and move the minute hand forward until the correct day is shown. Push the crown back to position 1.

Setting the time

Pull the crown out to position 3 and set the time. Push the crown back to position 1. (Consider AM/PM).

Setting the date

(not possible between 9.00 am and 12.30 am). Pull the crown out to position 2 and set the date. Push the crown back to position 1.